



LED Description

LED	Color	Function
Power	Green	Lit when power is available.
TX Link/Act	Off	Port link is down.
	Green	Lit when TP port works in 10M and 100M.
	Green Blinking	Blink when TP traffic is present (under 10M and 100M).
	Orange	Lit when TP port works in 1000M.
	Orange Blinking	Blink when TP traffic is present (under 1000M).
FO Link/Act	Off	Fiber link is down.
	Green	Lit when Fiber port works in 100M.
	Green Blinking	Blink when Fiber traffic is present (under 100M).
	Orange	Lit when Fiber port works in 1000M.
	Orange Blinking	Lit when Fiber traffic is present (under 1000M).



Lampor på Inteno CPE-switch

Din Inteno fiberkonverterare sköts helt av Zitius och har inga inställningsmöjligheter för dig som slutanvändare. Men det kan vara bra att känna till hur CPE-switchens lampor används.

Lampa	Färg	Beskrivning
PWR	Grön/Röd	Lyser grön då enheten får spänning. Lyser röd vid fel. Prova att starta om enhet genom att dra ut strömadaptern. Om fel kvarstår felanmäl tjänst.
WAN	Grön/Gul	Lyser vid länk på anslutning mot Internet. Blinkar vid datatrafik.
LAN1-4	Grön/Gul	Lyser vid länk mot anslutnen enhet. Blinkar vid datatrafik.

Färgen på lysdioderna visar aktuell hastighet på en port:

Gul	100 Mb/s
Grön	1000 Mb/s